Lab 1 — Peak Detection


Plot sensor data

```
In [1]: import numpy as np
import matplotlib.pyplot as plt
import os

     csv_filename = 'sample_sensor_data.csv'
     data = np.genfromtxt(csv_filename, delimiter=',').T
     timestamps = (data[0] - data[0, 0]) / 1000


     accel_data = data[1:4]
     gyro_data = data[4:-1]

     plt.plot(timestamps, accel_data[0])
     plt.show()
```




Assignment 1: Maximum point

```
In [1]: import numpy as np
      import matplotlib.pyplot as plt
      import os
      # Load CSV data
      csv_filename = 'sample_sensor_data.csv'
      data = np.genfromtxt(csv_filename, delimiter=',').T
      timestamps = (data[0] - data[0, 0]) / 1000
      accel_data = data[1:4]
      gyro_data = data[4:-1]
      # Find the peak
      def peak detection(t, sig):
          peaks = []
          \max val = -np. Inf
          N = len(sig)
          for i in range(N):
              if sig[i] > max val:
                  \max_{val} = sig[i]
                  position = t[i]
          peaks.append((position, max val))
          return np. array (peaks)
      max peaks = peak detection(timestamps, accel data[0])
      # Plot
      plt.plot(timestamps, accel data[0])
      plt.scatter(max_peaks[:,0], max_peaks[:,1], color = 'red')
      plt.title("Max Point Plot")
      plt.xlabel("Time")
      plt.ylabel("Meters per second")
      plt.show()
```



Assignment 2: local maximum point

```
In [2]: | import numpy as np
      import matplotlib.pyplot as plt
      import os
      # Load CSV data
      csv_filename = 'sample_sensor_data.csv'
      data = np. genfromtxt(csv filename, delimiter=','). T
      timestamps = (data[0] - data[0, 0]) / 1000
      accel_data = data[1:4]
      gyro data = data[4:-1]
      # Find the peaks using range-based maximum
      def peak detection(t, sig):
          peaks = []
          thres = 2
          window = 50 # window size for range
          N = len(sig)
          for i in range (window, N-window):
              if sig[i] > thres:
                  local range = sig[i-window:i+window+1]
                  if sig[i] == np. max(local range):
                      if not peaks or abs(t[i] - peaks[-1][0]) > 0.1: # 0.1 second minimum
                          peaks.append((t[i], sig[i]))
          return np. array (peaks)
      max peaks = peak detection(timestamps, accel data[0])
      # Plot
      plt.plot(timestamps, accel data[0])
      if len(max peaks) > 0:
          plt.scatter(max peaks[:,0], max peaks[:,1], color = 'red')
      plt.axhline(y=2, color='orange', linestyle='--', label='Threshold = 2')
      plt.title("Peak Plot")
      plt. xlabel ("Time")
      plt.ylabel("Meters per second")
      plt.legend()
      plt.show()
```



In []: